DAD-3003 Assembly Instructions for use with DAD-601 Compressor



Step 1 -- Assemble ¼ x ¼ Male Nipple to Outlet Port of Compressor



Step 2 – Assemble Female End of Air Saver Valve to Male End of Nipple



Step 3 – Assemble Female End of DAD-3003 Valve to Male End of Air Saver Valve then Assemble Air Hose to Outlet Port of DAD-3003